




Toucan Eco Active Plus Operation Guide




1
UnscREW the black lid from the empty 5L tank. Add one soluble salt sachet. There shouldn't be any water in the tank at this stage.




2
Open the lever valve to fill the tank up to the 5L mark.



3
Switch on the activator unit - the unit's light button will turn green. To activate press the green light button. It will turn blue and the activation process starts, which takes 45 minutes. You will see bubbles around the cell and a faint smell of chlorine once activated.



4
When the solution is activated the unit will beep and the blue light returns to green. The solution is now ready to dispense. The dispensers are set to deliver 20L at 100ppm via the bottle dispenser and 30L at 50ppm via the hose dispenser. The water pressure needs to be between 2 to 5 bar for the correct ppm to be made.



5
To make more solution, ensure the tank is empty and repeat the process again.

General maintenance

To pro-long the life of your Toucan Eco device and remove any build-up of salt or limescale, we recommend giving the holding tank a thorough clean once or twice a year.

To do this, switch off the system at the socket, fully drain the tank and fill with half white vinegar and half water. Leave for 30 minutes, drain and thoroughly flush the tank with cold water three times. Then wipe the inside of the tank with a microfibre cloth, remove both filters from within the tank and brush. You can also clean the filters in the dispenser unit, but make sure you switch off the main water supply first. We also recommend a more frequent flush with cold water once a month and a wipe to remove any residue salt from the outside of the equipment.



Scan code to watch maintenance video